

Installing the Ink Cartridge

Important Notes:

1. Turn off the printer (red push-button) before installing the ink cartridge.
2. Place the ink cartridge into the cartridge clip if the printer will not be used for over 20 minutes. The ink nozzles will dry out if not capped, damaging the cartridge!

Do not press hard when installing the cartridge! Damaging the contact pins will require replacement of the main board!

Installation procedures:

1. Place the cartridge into the slot at a 45 degree angle. The top edge of the cartridge should be roughly 1/4" away from the printer frame.



2. Gently push the cartridge forward from the back so it is not resting on the green lever. The top edge of the cartridge should be roughly 1mm about away from the printer frame.



3. Flip up the green lever to lock the cartridge into the correct position. The face of the cartridge will be slightly recessed from the metal face protectors. You may now power up the printer.



To take out the ink cartridge:

Flip the green lever down, and pull the cartridge up from the back with your thumb. Place the cartridge clip back onto the cartridge.

